Amaxa® Cell Line Nucleofector® Kit R

For COS-7 [ATCC® CRL-1651™ or DSMZ ACC60; cryopreserved]

African green monkey kidney; fibroblast-like cells growing in monolayers

Example for Nucleofection® of COS-7 cells



COS-7 cells (ATCC® CRL-1651™) were transfected with the Cell Line Nucleofector® Kit R, Program W-001 and 5 µg of pmaxGFP® Vector. Cells were analyzed 24 hours post Nucleofection® using light (A) and fluorescence microscopy (B).



Average transfection efficiency of COS-7 cells. COS-7 cells (ATCC® CRL-1658™ and DSMZ ACC60) were transfected with program W-001 and 5 µg of pmaxGFP® Vector. Cells were analyzed 24 hours post Nucleofection® by flow cytometry. Cell Viability was analyzed by using CellTiter-Blue™ assay (Promega)

Product Description

Cat. No.	**VCA-1001**
Size (reactions)	25
Cell Line Nucleofector® Solution R	2.25 ml (2.05 ml + 10% overfill)
Supplement	0.5 ml (0.45 ml + 10% overfill)
pmaxGFP® Vector (0.5 µg/µl in 10 mM Tris pH 8.0)	30 µg
Certified cuvettes	25
Plastic pipettes	25
Storage and stability	Store Nucleofector® Solution, Supplement and pmaxGFP® Vector at 4°C. For long-term storage, pmaxGFP® Vector is ideally stored at – 20°C. The expiration date is printed on the solution box. Once the Nucleofector® Supplement is added to the Nucleofector® Solution it is stable for three months at 4°C.

Required Material

Note **Please make sure that the entire supplement is added to the Nucleofector® Solution. The ratio of Nucleofector® Solution to supplement is 4.5 : 1. For a single reaction use 82 µl of Nucleofector® Solution plus 18 µl of supplement to make 100 µl of total reaction volume.**

- Nucleofector® Device
- Supplemented Nucleofector® Solution at room temperature
- Supplied certified cuvettes
- Supplied plastic pipettes
- Supplied pmaxGFP® Vector
- Substrate of interest, highly purified, preferably by using endotoxin-free kits; A260 : A280 ratio should be at least 1.8
- 6-well culture dish or culture system of your choice
- **For detaching cells**: 0.5 mg/ml Trypsin and 0.2 mg/ml EDTA in PBS and supplemented culture media or PBS/0.5% BSA
- **Culture medium**: DMEM (Lonza; Cat. No. BE12-604F) supplemented with 10% FCS and 1% Pen/Strep (100 µg/ml streptomycin, 100 U/ml penicilin)
- Prewarm appropriate volume of culture medium to 37°C (1.9 ml per sample)
- Appropriate number of cells (1 x 10^6 cells per sample; lower or higher cell numbers may influence transfection results)

1. Pre Nucleofection®

Cell culture recommendations

1.1 Replace media 2 – 3 times a week
1.2 Passage cells after reaching confluency
1.3 Seed out 2 – 2.5 x 10^6 cells/T162 flask
1.4 Subculture 1 day before Nucleofection® (4 x 10^6 cells/T162 flask)

Trypsinization

1.5 Remove media from the cultured cells and wash cells once with PBS; use at least same volume of PBS as culture media
1.6 For harvesting, incubate the cells ~5 minutes at 37°C with indicated trypsinization reagent (please see required material)
1.7 Neutralize trypsinization reaction with supplemented culture medium or PBS/0.5% BSA once the majority of the cells (>90%) have been detached

2. Nucleofection®

One Nucleofection® Sample contains

1 x 10^6 cells
5 µg plasmid DNA (in 1 – 5 µl H_2O or TE) or 5 µg pmaxGFP® Vector or 30 – 300nM siRNA (3 – 30 pmol/sample)
100 µl Cell Line Nucleofector® Solution R

2.1 Please make sure that the entire supplement is added to the Nucleofector® Solution
2.2 Prepare 6-well plates by filling appropriate number of wells with 1.4 ml of supplemented culture media and pre-incubate/equilibrate plates in a humidified 37°C/5% CO_2 incubator
2.3 Harvest the cells by trypsinization (please see 1.5 – 1.7)
2.4 Count an aliquot of the cells and determine cell density
2.5 Centrifuge the required number of cells (1 x 10^6 cells per sample) at 125xg for 10 minutes at room temperature. Remove supernatant completely
2.6 Resuspend the cell pellet carefully in 100 µl room-temperature Nucleofector® Solution per sample

Note **Avoid leaving the cells in Nucleofector® Solution for extended periods of time (longer than 15 minutes), as this may reduce cell viability and gene transfer efficiency.**

2.7 Combine 100 µl of cell suspension with **5 µg DNA**, 5 µg pmaxGFP® Vector or **30 nM – 300 nM** siRNA (3 – 30 pmol/sample) or other substrates
2.8 Transfer cell/DNA suspension into certified cuvette (sample must cover the bottom of the cuvette without air bubbles). Close the cuvette with the cap
2.9 Select the appropriate Nucleofector® Program **W-001** (**W-01** for Nucleofector® I Device)
2.10 Insert the cuvette with cell/DNA suspension into the Nucleofector® Cuvette Holder and apply the selected program by pressing the X-button
2.11 Take the cuvette out of the holder once the program is finished
2.12 Incubate the sample in the cuvette for 10 minutes at room temperature
2.13 Add ~500 µl of the pre-equilibrated culture medium to the cuvette and gently transfer the sample into the prepared 6-well plate (final volume 1.9 ml media per well). Use the supplied pipettes and avoid repeated aspiration of the sample

3. Post Nucleofection®

3.1 Incubate the cells in humidified 37°C/5% CO_2 incubator until analysis. Gene expression or down regulation, respectively, is often detectable after only 4 – 8 hours

Additional Information

For an up-to-date list of all Nucleofector® References, please refer to:
www.lonza.com/nucleofection-citations

For more technical assistance, contact our Scientific Support Team:

USA /Canada
Phone: 800 521 0390 (toll-free)
Fax: 301 845 8338
E-mail: scientific.support@lonza.com

Europe and Rest of World
Phone: +49 221 99199 400
Fax: +49 221 99199 499
E-mail: scientific.support.eu@lonza.com

Lonza Cologne AG
50829 Cologne, Germany

DCR-1019_2009-05